

```
In [1]: # interaction with operation system
import os
import sys
# allow python to access the paths of our/other python scripts
sys.path.append('../python') # use this if you do not have torch installed
# sys.path.append('../..//emg2pose/emg2pose/') # use this if you have torch i

# data manipulation/visualization
import numpy as np
import pandas as pd
import matplotlib.pyplot as plt

# custom script
from data import *
```

Loading the data

```
In [2]: datadir = '../data/emg2pose_dataset_mini/' #stored in the data respository
datalist = os.listdir(datadir) # list of datafiles in the directory

print('Working on dataset: ', datalist[0])
datah5 = Emg2PoseSessionData(os.path.join(datadir, datalist[0]))
```

Working on dataset: 2022-12-06-1670313600-e3096-cv-emg-pose-train@2-recording-13_right.hdf5

Exploring the data

```
In [70]: dir(datah5)
# print(datah5.no_ik_failure)
# print(datah5.slice)
```

```
Out[70]: ['DATASET_NAME',
          'EMG',
          'END_TIME',
          'HDF5_GROUP',
          'JOINT_ANGLES',
          'NUM_CHANNELS',
          'SAMPLE_RATE',
          'SESSION_NAME',
          'SIDE',
          'STAGE',
          'START_TIME',
          'TIMESERIES',
          'TIMESTAMPS',
          'USER',
          '__annotations__',
          '__class__',
          '__dataclass_fields__',
          '__dataclass_params__',
          '__delattr__',
          '__dict__',
          '__dir__',
          '__doc__',
          '__enter__',
          '__eq__',
          '__exit__',
          '__format__',
          '__ge__',
          '__getattr__',
          '__getitem__',
          '__getstate__',
          '__gt__',
          '__hash__',
          '__init__',
          '__init_subclass__',
          '__le__',
          '__len__',
          '__lt__',
          '__match_args__',
          '__module__',
          '__ne__',
          '__new__',
          '__post_init__',
          '__reduce__',
          '__reduce_ex__',
          '__repr__',
          '__setattr__',
          '__sizeof__',
          '__str__',
          '__subclasshook__',
          '__weakref__',
          '_file',
          'fields',
          'hdf5_path',
          'metadata',
          'no_ik_failure',
          'session_name',
```

```
'slice',  
'timeseries',  
'timestamps',  
'user']
```

```
In [63]: metadata = datah5.metadata  
print('Metadata: ')  
for key, val in metadata.items():  
    print('\t', key, ': ', val)
```

Metadata:

```
end : 1670314959.5166667  
filename : 2022-12-06-1670313600-e3096-cv-emg-pose-train@2-recordin  
g-13_right  
generalization : user  
held_out_stage : False  
held_out_user : True  
moving_hand : both  
num_channels : 16  
sample_rate : 2000.0  
session : 2022-12-06-1670313600-e3096-cv-emg-pose-train@2  
side : right  
split : val  
stage : TwoHandedFreeStyle  
start : 1670314722.55  
user : d387095792
```

```
In [165... import pandas as pd  
  
df = pd.read_csv(os.path.join(datadir, 'metadata.csv'))  
print('total sessions: ', len(df))  
  
print('\nParticipants: ', len(np.unique(df['user'])))  
  
print('\nStages: ', len(np.unique(df['stage'])))  
print(np.unique(df['stage']))  
  
df.head(10)
```

total sessions: 25253

Participants: 193

Stages: 29

```
['AllFingerPinchesThumbSwipeThumbRotate' 'CoffeePanicPete'  
'CountingUpDownFaceSideAway' 'CountingUpDownFingerWigglingSpreading'  
'DoorknobFingerGraspFistGrab' 'FastPongFronthandBackhandThrowing'  
'FingerAbductionSeries' 'FingerFreeform'  
'FingerPinchesSingleFingerPinchesMultiple' 'FingerTouchPalmClapmrburns'  
'FingerWigglingSpreading' 'GraspPunchCloseFar' 'HandClawGraspFlicks'  
'HandDeskSeparateClaspedChest'  
'HandOverHandAllFingerPinchesThumbSwipeThumbRotate'  
'HandOverHandCountingUpDownFingerWigglingSpreading'  
'HookEmHornsOKScissors' 'IndexPinchesMiddlePinchesThumbswipes'  
'IndividualFingerPointingSnap' 'OneHandedFreeStyle' 'PlayBlocksChess'  
'PokeDrawPinchRotateclosefar' 'PokePinchCloseFar' 'ShakaVulcanPeace'  
'ThumbsSwipesWholeHand' 'ThumbsUpDownThumbRotationsCWCCWP'  
'TwoHandedFreeStyle' 'WristFlexionAbduction' 'unconstrained']
```

Out [165...

	session	user	stage	start	
0	2022-04-07-1649318400-8125c-cv-emg-pose-train@2	29ddab35d7	ThumbsUpDownThumbRotationsCWCCWP	1.649400e+09	1
1	2022-04-07-1649318400-8125c-cv-emg-pose-train@2	29ddab35d7	ThumbsUpDownThumbRotationsCWCCWP	1.649400e+09	1
2	2022-04-07-1649318400-8125c-cv-emg-pose-train@2	29ddab35d7	HandClawGraspFlicks	1.649401e+09	1
3	2022-04-07-1649318400-8125c-cv-emg-pose-train@2	29ddab35d7	HandClawGraspFlicks	1.649401e+09	1
4	2022-04-07-1649318400-8125c-cv-emg-pose-train@2	29ddab35d7	ShakaVulcanPeace	1.649401e+09	1
5	2022-04-07-1649318400-8125c-cv-emg-pose-train@2	29ddab35d7	ShakaVulcanPeace	1.649401e+09	1
6	2022-04-07-1649318400-8125c-cv-emg-pose-train@2	29ddab35d7	HookEmHornsOKScissors	1.649401e+09	1
7	2022-04-07-1649318400-8125c-cv-emg-pose-train@2	29ddab35d7	HookEmHornsOKScissors	1.649401e+09	1
8	2022-04-07-1649318400-8125c-cv-emg-pose-train@2	29ddab35d7	HookEmHornsOKScissors	1.649315e+09	1
9	2022-04-07-1649318400-8125c-cv-emg-pose-train@2	29ddab35d7	HookEmHornsOKScissors	1.649315e+09	1


Plotting the data

```
In [91]: timestamp = datah5.timeseries[datah5.TIMESTAMPS] # nsamples vector
emgdata = datah5.timeseries[datah5.EMG] # 2darray nsamples x nchannels?
jointangle = datah5.timeseries[datah5.JOINT_ANGLES] # 2darray nsamples x njc

print('Timestamp shape:', timestamp.shape)
print('EMG shape:', emgdata.shape)
print('Jointangle shape:', jointangle.shape)

plt.plot(timestamp[:1000], emgdata[:1000,0])
plt.plot(timestamp[:1000], jointangle[:1000,:])
plt.show()
```

```
Timestamp shape: (473792,)
EMG shape: (473792, 16)
Jointangle shape: (473792, 20)
```



```
In [92]: from scipy.fft import fft, fftfreq

#deterime samplerate from timestamps
samplerate = metadata['sample_rate']
print('Recording freq {} Hz'.format(int(samplerate)))

N = int(samplerate/2) #Nyquist limit
T = 1.0 / samplerate
time = np.linspace(0.0, N*T, N, endpoint=False)
```

```

yf = fft(emgdata[:int(samplerate),0]) # Fourier transform
xf = fftfreq(N, T)[:N//2] # Frequencies of the transform

fig, axs = plt.subplots(2,1,figsize=(10,5))


axs[0].plot(time[:N], emgdata[:N,0], color='black') #data plot
axs[0].set_ylabel('intensity')
axs[0].set_xlabel('time (s)')

smoother = np.convolve(2.0/N * np.abs(yf[0:N//2]), np.ones(100)/100, mode='same')

axs[1].plot(xf, smoother, color='red', alpha=1, label = 'smoothed FFT') #data
axs[1].plot(xf, 2.0/N * np.abs(yf[0:N//2]), color='black', alpha=1, label = 'FFT')
axs[1].set_ylabel('power')
axs[1].set_xlabel('frequency (Hz)')
axs[1].legend()
plt.tight_layout()
plt.show()

```

Recording freq 2000 Hz



```

In [132]: # plot all channels for a length of data
length = 10 #seconds

print(emgdata.shape[0]/samplerate, 'sec of data')
print(emgdata.shape[0]/samplerate/60, 'min of data')

N = int(samplerate * length) #n values
T = 1.0 / samplerate
time = np.linspace(0.0, N, N, endpoint=False) * T

import matplotlib as mpl
cmap = mpl.colormaps['hsv']


fig = plt.figure(figsize=(10,5))
for i in range(12):
    plt.plot(time, emgdata[:N,i] + i*2000, linewidth=0.5, color=cmap(i/12))
plt.yticks(2000*np.arange(12), np.arange(12))

```

```
plt.ylabel('channel')
plt.xlabel('time (s)')
plt.show()
```

236.896 sec of data

3.9482666666666666 min of data



```
In [158... # Find when the hand is moving
# TAKEN FROM emg2pose utils
def get_contiguous_ones(binary_vector: np.ndarray) -> list[tuple[int, int]]:
    """Get a list of (start_idx, end_idx) for each contiguous block of True
    if (binary_vector == 0).all():
        return []

    ones = np.where(binary_vector)[0]
    boundaries = np.where(np.diff(ones) != 1)[0]
    return [
        (ones[i], ones[j])
        for i, j in zip(
            np.insert(boundaries + 1, 0, 0), np.append(boundaries, len(ones))
        )
    ]

def get_ik_failures_mask(joint_angles: np.ndarray) -> np.ndarray:
    """Compute mask that is True where there are no ik failures."""
    zeros = np.zeros_like(joint_angles) # (... , joint)
    is_zero = np.isclose(joint_angles, zeros)
    return ~np.all(is_zero, axis=-1)


angle_mask = get_ik_failures_mask(jointangle)

change_in_angle = np.diff(jointangle, axis=0)

fig = plt.figure(figsize=(10,5))
for i in range(20):
    plt.plot(time, jointangle[:N,i] + i, color=(0,i/20,0))
plt.fill_between(time, angle_mask[:N]*20, np.zeros(N), color='k', alpha=0.2,
```



```
plt.yticks(np.arange(20), np.arange(20))
plt.ylabel('joints angles')
plt.xlabel('time (s)')
plt.show()
```



```
In [159... # Plot when hand is moving, and what the sensor detects


length = 20 #seconds
N = int(samplerate * length) #n values
T = 1.0 / samplerate
time = np.linspace(0.0, N, N, endpoint=False) * T

windows = get_contiguous_ones(angle_mask)

import matplotlib as mpl
cmap = mpl.colormaps['hsv']

fig = plt.figure(figsize=(10,5))
for i in range(12):
    plt.plot(time, emgdata[:N,i] + i*2000, linewidth=0.5, color=cmap(i/12),
    plt.fill_between(time, angle_mask[:N]*12*2000, np.zeros(N), color='k', alpha
    for window in windows:
        if window[0]<N:
            plt.hlines(12*2000, window[0]/samplerate, window[1]/samplerate, colc

plt.yticks(2000*np.arange(12), np.arange(12))
plt.ylabel('channel')
plt.xlabel('time (s)')
plt.show()
```



Zoom in on a couple events

```
In [157... firststone = np.where(np.sum(emgdata[:N,:], axis=1)>500)[0][0]
print('Location of first event: ', firststone/samplerate)
window = firststone + 2000
fig = plt.figure(figsize=(10,5))
for i in range(12):
    plt.plot(time[firststone:window], emgdata[firststone:window,i] + i*1000,
            linewidth=1, color=cmap(i/12), zorder=10)
plt.fill_between(time, angle_mask[:N]*12*1000, np.zeros(N), color='k', alpha=0.5)
plt.xlim(firststone/samplerate, window/samplerate)
plt.yticks(1000*np.arange(12), np.arange(12))
plt.ylabel('channel')
plt.xlabel('time (s)')
plt.show()
```

Location of first event: 1.31

